

Product Data Sheet
MOHAWK POUR-N-WIPE™

M603-3016 Qt • M603-3017 Gal

Product Description:

Pour-N-Wipe™ is a very versatile finish with many applications in finishing, refinishing and restoration work. It imparts a lustrous satin finish, protecting wood against alcohol and water staining and is very mar-resistant.

Pour-N-Wipe is durable enough for use on hardwood floors, bar and table tops.

The finish can be easily rejuvenated by cleaning the surface with Mohawk Wax Wash.

Then, lightly sand the surface and apply a thin coat of Pour-N-Wipe™ following

directions. The surface will be dust free in 20 minutes. **Re-coat in four hours and**

hard enough in twelve hours to put the piece to service. New and stripped surfaces

can be finished without spraying, quickly leaving no brush marks or messy clean up.

Once you try Pour-N-Wipe, you will agree that it is a superior easy-to-use finish.

Advantages:

1. Wipes on as easily as furniture polish!
2. Provides a tough, alcohol resistant polyurethane finish.
3. Apply with a cloth or by a “squeegee” for large surfaces.
4. Pour-N-Wipe finish is self sealing.

Product Limitations:

1. Designed for interior use only.

Characteristics:

Weight per gallon: 7.25 ± 0.1 lbs./gal.

Flashpoint: 105F/40C

Package Viscosity: 55-60KU/ 100 grams

Dry time: Air dry @ 72F, 35% RH

To touch: 45 minutes

Tack free: 90 minutes

To handle or recoat: 4 hours

Volatile Organic Compounds (VOC):

535.38 GPL, 4.46 lb/gal

Spec. Gravity: .87 ± 0.01

Solids % (wt.): 38.02

Solids % (vol.): 30.89

VHAPs: .0001

Coverage: 495 sq. ft./gal. @ 1 dry mil

Package Life: 3 years

HMIS: Health: 1, Flammability: 2, Reactivity: 0, Personal Protection: X

Specifications:

Directions:

PREPARATION INSTRUCTIONS:

For rejuvenation of a current finish, sand the surface lightly with 320 grit sandpaper and remove dust and debris.

For best results, clean with Mohawk Wax Wash before applying Pour-N-Wipe®.

When finishing or refinishing, prepare the surface by sanding wood to no higher than 180 grit sandpaper. Stain if desired, following manufacturer's directions and dry time. Remove sanding dust and debris from surface.

APPLICATION DIRECTIONS:

For Best Results:

The work area, surface being finished, Pour-N-Wipe should be above 60°F. Maintain 60 degrees throughout the dry time of the coats.

Colder temperature can affect flow and dry times.

Use in a well-ventilated area. Pour a small amount of Pour-N-Wipe™ onto the surface. Use a soft rag to wipe first across the grain, followed by a uniform wipe with the grain.

Allow 4 hours to dry and lightly sand with 320 grit sandpaper before applying additional coats. **After final coat, allow to dry a minimum of 12-hours before putting the piece into service.** Sheen will increase slightly with each additional coat.

CLEANUP:

Use Mohawk M650-230 Mineral Spirits for cleaning up.

Read & Follow All Label Cautions
Keep Out of the Reach of Children
PROTECT EYES & SKIN
Keep away from Heat, Sparks & Flame
Use Only with Adequate Ventilation

available

Shellac.net Wood Finish Supply |

MeritIndustries.com

Authorized Mohawk Distributor

707-299-8016
