

AquaCoat



eco-friendly water-based wood finishes

Clear Grain Filler

Eco-friendly



BENEFITS

- Waterborne Clear Grain Filler dries in 30-45 minutes for a faster build
- Crystal clear when dry
- Easy sanding
- Nonflammable
- Low odor and low VOC
- Can be tinted with water-soluble colorants or dyes
- Can be thinned with water
- Soap and water clean-up

Do Not let product freeze.

Made In The USA

Aqua Coat Clear Grain Filler is the secret to obtain a smooth-as-glass factory finish on wood products and furniture being refurbished. Clear Grain Filler works on all types of wood including kitchen cabinets, dressers, tabletops, wooden boxes, fine instruments, and more.

PRODUCT DESCRIPTION

Essential for a fine quality finish, this waterborne, easy-to-sand, clear gel grain filler is used to fill the pores in open and coarse grain woods, such as oak, ash, and other hard-to-fill woods. Aqua Coat Clear Grain Filler can be tinted with water-soluble colorants or dyes. The filler may be used on raw wood or after staining or sealing. Aqua Coat Clear Grain Filler dries "Crystal Clear". Thin with water if needed.

RECOMMENDED USES

Used by furniture makers and refinishers, DIYers, cabinet makers, Luthiers, gun stock finishers, and woodworking professionals.

Highly recommended for: guitar-making, piano restoration, antique restoration, furniture upcycling and kitchen cabinet refinishing.



Clear Grain Filler

Eco-friendly

EASY TO USE

SURFACE PREPARATION: Surface must be clean and dry (free from all dirt, oil, wax and polish). Sand the surface thoroughly. Remove all dust with a vacuum, forced air, or a cloth damp with water.

DIRECTIONS FOR USE: Aqua Coat Clear Grain Filler can be applied on raw wood or after the wood is stained. A seal coat of Dewaxed Shellac or a seal coat of Aqua Coat X-119 sanding sealer before application of the grain filler is recommended.

Clear Grain Filler may be applied with a soft cloth, using a circular motion, much like applying a paste wax, or worked generously into open wood grain pores with a small squeegee or flexible putty knife. Inspect to see if the grain is filled, then scrape or squeegee to remove excess. Let dry 30-45 minutes, then lightly sand with 320-grit paper. If grain is not filled, repeat the application process. 2 - 3 coats of Grain Filler are recommended depending on the grain structure.

- Allow overnight dry time.
- Topcoats are required
- Easy clean-up with soap and warm water.



AquaCoat



eco-friendly water-based wood finishes



Aqua Coat Clear Grain Filler is the secret to a smooth finish on open pore and coarse grain woods!



www.aquacoat.com

available from:

Shellac.Net Wood Finish Supply
MeritIndustries.com

Toll-free: 877-245-5611

for more information or to purchase, see:

www.shellac.net/clear-wood-grain-filler-moreinfo.html